

# Secure Payment Systems

## Nurit 2085 / 2085+ / 3000 / 8000 series LOYALTY INSTRUCTIONS

1. Press the Payment Mode button to scroll through the payment options to find SPS LYL 1.00:
  - a. Credit
  - b. Debit
  - c. SPS LYL 1.00

2. At the SPS LYL 1.00 payment option will display: SPS LYL 1.00: Swipe Card ...

Please swipe the loyalty card to be activated or used ... The screen will display: 1. Activation

- i. Press 1 or "Enter" to "Activate" a new loyalty card.

*(Please note: activating an already active loyalty card will clear any existing balance. If the card has already been activated as a gift card, it does not need to be activated as a loyalty card.)*

You will see "Master/MGR Password" (if this option is turned on). Please type a password and press enter.

**Enter Ref Num** – Manually type the Activation Reference Number printed on back of the loyalty card

**Enter Amount \$** - Please type in the Activation amount and then press enter

- ii. Press 2 to run a "Purchase" using a previously issued loyalty card. Type the amount and then press enter. (This function will add loyalty value to the card)
- iii. Press 3 to "Redeem Loyalty" once the consumer has reached a certain reward level (as printed on a "purchase" receipt). Please type in the reward level (i.e. 1, 2, 3, etc...) and press enter. The individual stores determine reward levels and redemptions.
- iv. Press 4 to perform a "Transfer" for cardholders wishing to transfer their balance to another loyalty card of the same retail chain. (If there is a gift card balance, this function will transfer the existing gift balance as well). You must first activate a new card for \$0.00 You will be asked to swipe Card 2 (the card you want the funds to go onto).
- v. Press 5 to perform a "Balance Inquiry" on an existing loyalty card (a receipt is not printed for this option). You will also see the gift card balance displayed.
- vi. Press 6 to run a "Card Detail" report displaying all historical transactions run on that given card.
- vii. Press 7 to perform a "Card Summary" displaying the summary of all the transactions on a specific card. (We suspect this feature will not be used often, as the Card Detail provides a more beneficial report).

Note: You may use the arrow buttons to cycle thru all the above options. Simply press Enter at the desired choice.

3. SPS Batch Close / Host Detail Report / Reprint Receipt Functions / Manager Password Creation  
*(Note: Loyalty transactions do not have a batch to close)*

- A. Press **Batch/Alt** Button ... You will see displayed: "Choose Host"
- B. Press the down arrow button to select **SPSSVL Gn** then press Enter
- C. Select the desired function by pressing the down arrow button (or up arrow when reaching the end)
  - i. **Reprint** - press Enter ... the terminal will display "Item Number"
    - a. Type in the desired item number of the receipt desired and then press Enter
  - ii. **Password** - Press enter to display "Master Pass" Type in the Master Password and press enter:
    - a. New Password – Press enter to create a Manager Password
    - b. Delete Password – Press enter to delete an existing Manager Password
    - c. View Passwords – Press enter to view existing Manager Passwords
  - iii. **Lyl Str Det (Loyalty Store Detail)**— press Enter ... the terminal will display "Date: MMDDYY"  
Press Enter for today's detail report or enter in a date for a detail report from a prior day.  
Note: this report prints the item number of specific transactions.
  - iv. **Lyl Str Sum (Loyalty Store Summary)**— press Enter ... the terminal will display "Date: MMDDYY"  
Press Enter for today's summary report or enter in a date for a summary report from a prior day.  
Note: this report provides a total of each type of transaction performed.